

Battery Life/No. of Shots

	Memory Stick Media		Microdrive	
Still Image	Approx. 185 min	370 shots	Approx. 175 min	350 shots

The LCD screen is turned on.

Shooting one photo every 30 seconds.

The zoom is switched alternately between the W and T ends.

The flash strobos once every two times.

The power turns on and off once every ten times.

Note that the actual numbers may be less than indicated depending on the condition of use.

Voice Memo	40 sec
------------	--------