

# DSC-S60 Media Charts

\* Number of images recorded on a single media (Approx. No.of shots)

	Memory Stick media				Memory Stick PRO media				Internal Memory
	MSA-16A/AN	MSH-32	MSH-64	MSH-128	MSX-256S/N	MSX-512S/N	MSX-1GN	MSX-2GN	32MB
<b>Normal : Fine/Standard</b>									
5M (2,592 x 1,944)	6 / 11	12 / 23	25 / 48	51 / 96	92 / 174	188 / 354	384 / 723	789 / 1482	12 / 23
5M (2,592 x 1,728) 3 : 2	6 / 11	12 / 23	25 / 48	51 / 96	92 / 174	188 / 354	384 / 723	789 / 1482	12 / 23
3M (2,048 x 1,536)	10 / 18	20 / 37	41 / 74	82 / 149	148 / 264	302 / 537	617 / 1097	1266 / 2250	20 / 37
1M (1,280 x 960)	24 / 46	50 / 93	101 / 187	202 / 376	357 / 649	726 / 1320	1482 / 2694	3038 / 5524	50 / 93
VGA (640 x 480)	97 / 243	196 / 491	394 / 985	790 / 1975	1428 / 3571	2904 / 7261	5928 / 14821	12154 / 30385	196 / 491
VX Fine** (640x480)					177	362	740	1518	
VX Standard** (640x480)	42	87	176	354	642	1307	2667	5469	87
Video Mail** (160x112)	672	1362	2739	5493	10281	20825	42262	87505	1362

(\*1) When recording 10 frames per Clip Motion file

(\*2) When recording 2 frames per Clip Motion file

\*\* MPEG Movie / Voice memo Continuous recording time (Maximum)

# DSC-S60 Battery Chart

## Battery Life/No.of Shots

### CIPA

#### Supplied Battery (Alkalaine)

Still Image	Approx. 50 min	Approx. 100 shots
<b>Optional NH-AA2DA Battery</b>		
Still Image	Approx. 220 Min	Approx. 440 shots
<b>Optional NH-AA2DB Battery</b>		
Still Image	Approx. 255 Min	Approx. 510 shots
<b>Optional NP-NH25 Battery</b>		
Still Image	Approx. 255 Min	Approx. 510 shots

Image quality "FINE"

The LCD screen is turned on

Shooting one time every 30 seconds

The zoom is switched alternately between the W and T ends

The flash strobes once every two times

The power turns on and off once every ten times

Note that the actual numbers may be less than indicated depending on the condition of use