

* Battery Life/No.of Shots

| | | |
|-------------|----------------|-------------|
| Still image | Approx. 85 Min | Approx. 170 |
|-------------|----------------|-------------|

The LCD screen is turned on

Shooting one photo every 30 seconds

The zoom is switched alternately between the Wide and Telephoto ends

The flash strobos once every two times

The power turns on and off once every ten times.

Using "Memory Stick"

Note that the actual numbers may be less than indicated depending on the condition of use.